


User Manual

XPERIENCE



1:Home page:



2:Menu ON/OFF:

The image shows a digital control interface for a motorhome, titled "XPERIENCE". The interface displays several key metrics and control options:

- Battery Status:** Two large circular gauges show 100% battery level. A smaller gauge shows 60% battery level.
- Autonomie:** A battery icon with "60%" is shown next to the text "Autonomie : 4j 3h 35m" and a red arrow pointing to "-3A 12V".
- Time and Date:** The time "8:30" is displayed, along with "JUNE" and "JANVIER".
- Temperature:** A thermometer icon shows "22°C".
- Controls:** A vertical sidebar on the right contains several toggle switches:
 - Light:** A lightbulb icon with a green toggle switch.
 - Heater:** A heater icon with a green toggle switch.
 - Pump:** A pump icon with a green toggle switch.
 - AUX:** An "AUX" label with a green toggle switch.
 - ON/OFF:** A master "ON/OFF" toggle switch.
- Icons:** At the top right, there are icons for 230V power, a USB symbol, a Wi-Fi symbol, and a key symbol.

Blue arrows point from text boxes to the corresponding controls:


- Light:** Points to the Light toggle switch.
- Heater:** Points to the Heater toggle switch.
- Pump:** Points to the Pump toggle switch.
- AUX:** Points to the AUX toggle switch.
- ON/OFF:** Points to the master ON/OFF toggle switch.

Text boxes provide details for the ON/OFF and AUX controls:

- ON/OFF:**
 - Heater
 - Light
 - Pump
 - AUX
- AUX:**
 - Electrical Roof bed
 - USB socket
 - Autoradio

3:Setting alarm on waste and fresh water tank:

To get this page, you have to press tank button on home page




Setting alert fresh water

Setting alert Waste water

4: Battery setting:

To get this page, you have to press Battery button on home page




Setting Battery model and Amp level

5:Setting Heater :

To get this page, You have to press on Heater tab on home page

Adjustment temp setting

Adjustment heating speed from boiler



Truma/Alde 230V:
Possibility to choose the electrical resistance power and use or not GAZ bottle

6:Stand by:

Automatic standby, every 60 sec, a new click on the screen reactivate the tablet.



11:45