


User Manual

XPERIENCE



1:Home page:



2:Menu ON/OFF:

The screenshot displays the XPERIENCE control interface. At the top, there is a header with a question mark icon, the word "XPERIENCE", and several status icons (230V, USB, Wi-Fi, and a key icon). Below the header, there are two large circular gauges, both showing 100%. To the left, a battery icon shows 60% charge, with a red arrow pointing to "Autonomie : 4j 3h 35m" and "-3A 12V". A green "Zz" icon is also present. In the center, there is a 3D rendering of a motorhome. On the right side, there is a vertical control panel with several toggle switches. A callout box labeled "ON/OFF:" lists the following items: -Heater, -Light, -Pump, and -AUX. Another callout box labeled "AUX:" lists: -Electrical Roof bed, -USB socket, and -Autoradio. A third callout box labeled "Pump" points to the pump icon. A fourth callout box labeled "Light" points to the light icon. A fifth callout box labeled "Heater" points to the heater icon. The interface also shows the time "8:30" and the date "LUNE" and "JANVIER".

Light

Heater

100%

100%

60%

Autonomie :
4j 3h 35m
-3A
12V

Zz


ON/OFF:
-Heater
-Light
-Pump
-AUX

Pump

AUX:
-Electrical Roof bed
-USB socket
-Autoradio

3:Setting alarm on waste and fresh water tank:

To get this page, you have to press tank button on home page



Setting alert fresh water

Setting alert Waste water

4: Battery setting:

To get this page, you have to press Battery button on home page

Autonomie :
4j 3h 35m

-3A
12V

Plomb AGM Gel Lithium

Ah **100 Ah** ▾

ON / OFF


Setting Battery model and Amp level

5:Setting Heater :

To get this page, You have to press on Heater tab on home page

Adjustment temp setting

Adjustment heating speed from boiler



Truma/Alde 230V:
Possibility to choose the electrical resistance power and use or not GAZ bottle

6:Stand by:

Automatic standby, every 60 sec, a new click on the screen reactivate the tablet.



11:45